

WAC 296-874-30022 Prevent swaying of two-point and multipoint suspension scaffolds. You must tie or use other means to keep two-point and multipoint suspension scaffolds from swaying, if an evaluation by a competent person determines it is necessary.

Note: Window cleaners' anchors **cannot** be used to secure scaffolds since they are not designed to withstand the load.

[Statutory Authority: RCW 49.17.010, 49.17.040, 49.17.050. WSR 15-23-086, § 296-874-30022, filed 11/17/15, effective 12/18/15. Statutory Authority: RCW 49.17.010, 49.17.040, 49.17.050, 49.17.060. WSR 05-01-054, § 296-874-30022, filed 12/7/04, effective 3/1/05.]