

WAC 296-806-43010 Protect employees when removing scale. You must protect employees at every hammer and press by:

(1) Making sure they do not place a hand or arm between the dies by providing them with devices that reach the full length of the die when removing scale. Examples include:

(a) Oil swabs.

(b) Scale removers.

(c) Other devices that remove scale by reaching the full length of the die.

(2) Stopping flying scale through construction and arrangement of a scale guard that is *of substantial construction* at the back of every hammer and press.

[Statutory Authority: RCW 49.17.010, 49.17.040, 49.17.050, 49.17.060. WSR 15-24-102, § 296-806-43010, filed 12/1/15, effective 1/5/16; WSR 04-14-028, § 296-806-43010, filed 6/29/04, effective 1/1/05.]