

WAC 296-869-20040 Before and during use. (1) You must set the brakes and make sure outriggers, when used, are positioned on pads or a solid surface.

(2) You must install wheel chocks when using the aerial lift on an incline if they can be installed safely.

[Statutory Authority: RCW 49.17.010, 49.17.040, 49.17.050. WSR 15-23-086, § 296-869-20040, filed 11/17/15, effective 12/18/15. Statutory Authority: RCW 49.17.010, 49.17.040, 49.17.050, 49.17.060. WSR 06-19-073, § 296-869-20040, filed 9/19/06, effective 1/1/07.]