

WAC 296-304-08005 Hand tools. (1) You must not issue or permit the use of unsafe hand tools.

(2) Wrenches, including crescent, pipe, end and socket wrenches, must not be used when jaws are sprung to the point that slippage occurs.

(3) Impact tools, such as drift pins, wedges, and chisels, must be kept free of mushroomed heads.

(4) The wooden handles of tools must be kept free of splinters or cracks and must be kept tight in the tool.

[Statutory Authority: RCW 49.17.010, 49.17.040, 49.17.050, and 49.17.060. WSR 17-18-075, § 296-304-08005, filed 9/5/17, effective 10/6/17; Order 74-25, § 296-304-08005, filed 5/7/74.]