

**WAC 296-806-41508 Follow these requirements for compactors that cycle automatically.** You must use automatic cycling controls only on compactors where the loading chamber is located so that it cannot be accessed during operation.

[Statutory Authority: RCW 49.17.010, 49.17.040, 49.17.050, 49.17.060. WSR 15-24-102, § 296-806-41508, filed 12/1/15, effective 1/5/16; WSR 04-14-028, § 296-806-41508, filed 6/29/04, effective 1/1/05.]